

Care Instructions

Laminex™ laminates do not easily scratch or chip and will withstand normal wear and tear. They are also stain resistant therefore the best cleaning agent for laminate surfaces is clean water and mild detergent. It is also recommended that you rinse detergent off with a clean, damp cloth and dry with a microfibre cloth.

Spills

With some accidental spills you must take prompt action. Wipe off beetroot and berry juices, first aid preparations, concentrated bleach, dishwasher detergents and artificial dyes or hair colouring immediately. Acid based ceramic cleaners, oven cleaner and limescale removers must not be used as they can cause permanent staining. Any spillage or splashes of these cleaners must be washed off the laminate surface immediately. Specialty glue types such as Super Glue can also be removed immediately with acetone (typically found in Nail Polish remover).

Stains

If an organic stain cannot be removed with Ajax Spray 'n' Wipe with Baking Soda try methylated spirits or dab the stain with a diluted bleach mixture (or Organic Stain Remover from Born). Leave for 3 minutes then wash off with water and dry.

Please note that insufficiently diluted bleach may irreversibly damage the laminate surface. Using a Nylon Bristled Nail Brush or Microfibre Sponge can increase the effectiveness of cleaning agents especially on textured surfaces. Test on a small patch first before applying to the full surface. Always be careful on laminate joins and edges as these products can break down the adhesive used to bond your Laminex™ laminate to the substrate. Ink marks from felt-tip and ball-point pens can be removed with a suitable solvent such as methylated spirits or acetone on a clean cloth. Solvents such as methylated spirits and acetone are highly flammable. Use with proper caution.

After using a cleaner, the surface should be rinsed with clean water and wiped or buffed dry with a soft cloth.

If the surface is not rinsed with clean water following the use of cleaning agents it is possible for a film to remain on the surface which then shows marks. A melamine sponge (commonly known as a magic sponge or Eraser) is also useful to remove marks and stains. Available from most supermarkets.

Streaks

Streaky marks sometimes show on dark colours and gloss surfaces. After cleaning use a glass cleaning product such as Mr Muscle Surface & Glass or Ajax Spray 'n' Wipe glass cleaners.

Grease

Clean, hot soapy water will deal with greasy marks. If needed, dab, wait and wipe away. Finish off with a glass cleaner.

Scratches

Laminex™ laminates will withstand normal wear and tear but can be damaged by scratching or cutting with utensils, knives and unglazed pottery. Darker colours and gloss surfaces show scratches more readily than lighter colours. To minimise scratching, always place and lift objects from the surface. Never drag or slide them across the surface.

Avoid

- Don't place appliances or hot pots straight from the oven/stove directly on to your Laminex[™] laminate surface.
- Avoid scourers and abrasive cleaners. They will damage the surface.
- Furniture polishes should not be used, as a build up
 of silicone wax on the surface may result in eventual
 discolouration and smear marks which can be very
 difficult to remove.
- $\bullet~$ Don't cut directly on $\; Laminex^{\scriptscriptstyle{\mathsf{M}}} \; laminate \; surfaces.$
- Don't place burning cigarettes on to Laminex[™] laminate surfaces.
- Don't place boiling jugs or leave water puddles on joins as it may penetrate the join.

Quick reference

Care and maintenance for individual Laminex™ Laminate finishes.

<u>V</u>elour

A damp cloth removes spills and greasy spots. Clean with warm soapy water to remove heavy built up dirt. Use glass cleaners such as Mr Muscle Surface & Glass Cleaner or Ajax Spray n' Wipe glass cleaners or rub with a clean, dry cloth to bring back brightness. Special attention must be made to removing all of the cleaning solution especially when degreaser solutions are used.

Paper Terrazzo

Deep textured finishes are inevitably more difficult to clean than smooth surfaces. For built up dirt in textured surfaces, use a nylon bristled hand of vegetable brush in conjunction with clean hot soapy water. Clean the soiled area using a rotating motion. Rinse and dry the surface with a clean dry cloth.

Gloss Plus & Satin

A damp cloth removes spills and greasy spots. Clean with warm soapy water to remove heavy built up dirt. Use glass cleaners such as Mr Muscle Surface & Glass Cleaner or Ajax Spray n' Wipe glass cleaners or rub with a clean, dry cloth to bring back brightness.

Alucci™

A damp cloth removes spills and greasy spots. Clean with warm soapy water to remove heavy built up dirt. Use glass cleaners such as Mr Muscle Surface & Glass Cleaner or Ajax Spray n' Wipe glass cleaners or rub with a clean, dry cloth to bring back brightness. Special attention must be made to removing all of the cleaning solution especially when degreaser solutions are used.

